


# RR-476 MULTI CUTTER



Index No.	Parts No.	Description	Index No.	Parts No.	Description
1	51901	Motor Housing	25	051825	Ball Bearing (2) (607zz)
2	30102	Spring Pin (3x24)	26	51926	Work Housing
3	51803	Air Inlet	27	51827	O-Ring (14.8x2.4)
4	51204-23SUB	Throttle Lever	28	51826	Knob
5	51205	Valve Stem	29	51929	Work Spindle
6	51706	Bushing	30	51830	Washer
7	70107	O-Ring (4.8x1.9)	31	51831	Screw (M8x20)
8	51208	Spring	32	51932	Disk Washer (3)
9	70123	O-Ring (11.8x2.4)	33	51833	Oscillator
10	51210	Throttle Valve Plug	34	51828	Clamp (1-1/4")
11	40305	O-Ring (6.5x2)	35	52237	Oil Cap (7/32")
12	51212	Spacer	36	51936	Screw (4) (#8x3/4")
13	030113	Ball Bearing (626zz)	37	51937	Crank Shaft
14	59214	Rear End Plate	38	051838	Ball Bearing (2) (6900zz)
15	51915	Rotor	39	51839	Oil Seal
16	51916	Rotor Blade (4)	43	40147	Spring Washer (4) (M4)
17	70117	Spring Pin (3) (2x5)	44	51843	Packing
18	51918	Cylinder	48	10018	Hex. Key Wrench (5mm)
19	51919	Front End Plate	49	51812-11SUB	Exhaust Hose
20	051220	Ball Bearing (6000zz)	*50	51850-10	Side Handle
21	51221	Air Regulator	*51	51850-11	Screw
22	51922	Spacer	52	51912	Gasket
24	51824	Clamp Nut			

\*Optional parts

519-0000